


## 3 Lever Lock




PLEASE READ INSTRUCTIONS CAREFULLY

BEFORE BEGINNING INSTALLATION

Determine the latch direction according to door handing as shown in g.1.




2. Refer to g 2, if the latch direction needs reversing.




3. Position lock in mortise and mark around outer for-end. Remove the lock and

create a recess 4.7mm deep at the previously marked position. Remove the outer for-end, replace the lock. For re door application use intumescent packs (1 pack per latch / lock, 1mm for 30 mins. & 2 mm for 60 mins.).

4. Insert lock into door and secure with screws supplied determine the position of the strike on the door frame and x as required g. 3 & 4



g. 3




g. 4

**Product Maintenance & Safety :-** Please ensure that the operation of the lock and ensure that all fixings are secure and adjust if required. These checks must be carried out every 3 months. Ensure that the strike plate / box keep is correctly in line and that the door has not dropped. Also ensure that the strike plate/box keeps are completely clear of any obstructions and that both latch bolts and Deadbolts are clear to enter without problems.

**Warning :-** The Safety features of this product are essential to its compliance with EN 12209. No modification of any kind, other than those described in these instructions are permitted.

For Dead Lock skip Latch reversal step (i.e. 2).

	<b>i-CE Locking Systems</b> Distributed by Lunn Hardware Unit 18 Bramshall Industrial Estate, Uttoxeter ST14 8TD											
	Certificate	BS EN 1935 : 2002	1	M	4	1	0	F	1	B	G	1

For Declaration of performance please go to: [www.i-celocks.co.uk](http://www.i-celocks.co.uk)

